

BACK OF VALVE WITHOUT COVER

## **Product Features**

- Simple mechanical design is easy to understand
- Two valve body designs: one for downflow regeneration and one for upflow (covers every valve in the 5600 family - quick access to all internal components)
- Injector/drain modules containing the brine valve, flow controls and injector are removable from the valve's exterior
- Ruggedly built timer is designed with heavy-duty 3/8<sup>-</sup> wide plastic gears
- 5600 controls are user friendly and easy to program
- Non-corrosive, UV-resistant Noryl® valve body
- Choice of 7 or 12 day clock or demand regeneration with either mechanical or electronic meter
- Economical small annual power consumption; keeps the time and activates the piston/valve mechanics with a single motor
- · Designed with double backwash

## **Options**

- Bypass valve (Noryl® or lead-free brass\*\*)
- · Backwash filter
- Upflow regeneration
- 35 day timer
- Low water use piston (uses as little as 29 gal./ regeneration)
- Meter initiated regeneration
- · Auxiliary switches

Valve material	Noryl®*
Inlet/Outlet	3/4", 1", 1-1/4" NPTF
Cycles	7

Flow Rates (50 psi Inlet) - Valve Alone

Continuous (15 psi drop)	20 GPM
Peak (25 psi drop)	26 GPM
CV (flow at 1 psi drop)	5.0
Max. backwash (25 psi drop)	7 GPM

Regeneration

Valve Specifications

Downflow/Upflow	Both
Adjustable cycles	Brine flow only
Time available	180 minutes

Meter Information

Meter accuracy range	.25 - 15 GPM +/- 5%
	Standard: 125 - 2,125 Extended: 625 - 10,625

**Dimensions** 

Distributor pilot	0.8125" or 1.050" pipe O.D.
Drain line	1/2" NPTF
Brine line	1600 - 3/8"
Mounting base	2-1/2" - 8 NPSM
Height from top of tank	7"

Typical Applications

Water softener	6"-12" diameter
Iron filter	6 <sup>-</sup> -10 <sup>-</sup> diameter
Sediment filter	6"-10" diameter
Carbon filter	6 <sup>-</sup> -10 <sup>-</sup> diameter
Neutralizing filter	6"-10" diameter

Additional Information

Injector brine system	1600
Electrical rating	24 v, 110 v, 220 v - 50 Hz, 60 Hz
Max. VA	3
Estimated shipping weight	Time clock: 5 lbs.
	Metered valve: 6 lbs.
Pressure	Hydrostatic: 300 psi
	Working: 20 - 120 psi
Temperature	34° - 110° F

Approvals

WQA Gold Seal system	0.5 - 2.0 cu. ft.
UL registered component	

\*Noryl is a registered trademark of General Electric Company.

\*\*As defined in the Safe Drinking Water Act.



